

Smart Projector



Quick Installation Guide



Attention

Please read this manual carefully before use and keep it for future reference.

1. The projector is non dustproof or waterproof.
2. In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
3. Please use the original power adapter. The projector should work under specified rated power supply.
4. When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
5. Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.
6. Regularly clean projector vents, or dust may cause cooling malfunction.
7. Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.
8. Please handle with care during daily use.
9. Please cut off the power if the projector is out of use for long time.
10. Non-professionals are forbidden to disassemble the projector for testing and maintenance.

Structure description

This manual is for reference only. It is subject to change without prior notice. Hotack reserves the right of final interpretation.



Package Contents


Please check and ensure that the projector (hereinafter referred to as the "equipment") is in good condition, and all the following components are included in the packaging.



Master



Remote Controller




Power Cord



User Guide

Remote Component and Functions



Mouse Mode

Remote Component -> My Apps: Netflix  -> Mouse 
Enter mouse mode

Operations on Mouse mode:

Directions: Mouse movement

Page: Slide up and down

Slide: Slide left or right



Switch in the Applications

Click on "Apps" to view installed programs. click program icon to switch between applications.

Move to "My Apps", click OK to enter.

All Apps can be clearly distinguished from the icons.




Settings

Enter to setup Networking, Bluetooth, Projection, Source, Audio, System.



Networking Setting

Settings * Networking Setting * WIFI setting, WIFI "ON", select objective WIFI ID and input password to connect internet.



Bluetooth Setting

Settings > Bluetooth, Bluetooth "ON", click Refresh Device and choose objective device to pair.



Image Setting

Settings > Image, Setting Projection, Set different picture modes: Standard, Movie, Vivid, and Custom.



Audio Setting

Setting » Audio setting, Mute key sound.



System Setting

Setting » System, enter to access language settings, input method, time zone, system upgrade, factory reset, and system information.



Miracast

Ensure that Android devices (phone, pad, ect) are in the same local wireless LAN with these devices.

Operations on Devices:

Home Screen->My Apps->Miracast->Open miracast service->Turn on the phone mirroring->Connection.



Operations Android phone devices.



Airplay

Ensure that Apple devices (iphone, pad, ect) are in the same local wireless LAN with these devices.

Operations on Devices:

Home Screen->APPS->My APPs->TV Casting-Turn on the phone mirroring-Connection.



Operations iphone devices.



Download the TV Casting App on Your Phone

Scan the QR code on the screen or search "TV Casting" in the App Store (iOS) or on Google Play (Android) to download TV Casting on your mobile device.



TV Casting app interface and functions.



Safety instructions

Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector.

Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.

Projector should be kept away from flammable, explosive, strong electromagnetic interference (large radar stations, power stations, substations), etc. Strong ambient light (avoid direct sunlight), etc.

Do not cover projector vents.

Please use the original power adapter.

Keep adequate ventilation and make sure vents are not covered to avoid projector overheating.

When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain.

Do not bend or drag the power cord.

Do not put power cord under projector or any heavy objects.

Do not cover other soft materials on power cord.

Do not heat the power cord.

Avoid touching power adaptor with wet hands.

Disclaimer

This manual is general instructions, The pictures and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice.

Please keep your device properly. We are not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons, we are not responsible for any loss of any third party claims.

This manual has been carefully checked by professional engineer, please understand for any inevitable omissions.

Attention:

Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes, kids should use the projector under the supervision of adults.

Contact Us

Thanks for choosing our digital photo frame. If you have any questions or problems with our products, feel free to contact our customer support team at **serviceforb-m@outlook.com** or call **1-888-968-5188**. We typically respond within 24 hours. Your satisfaction is our priority.